

**PRIMER 1200**

**Technical Sheet**

**NAME:**

**TYPE:**

**USE:**

**COMPOSITION:**

**CHARACTERISTICS:**

**PRIMER 1200**

White water-based primer

Acil-siloxane waterbased primer for interior and exterior easy to apply.

special resins and charges allowing breath-

**specific weight:** 1.550 ± 30 gr/LT. at 20°C

**viscosity** 8000 cps

**yield:** 8 - 10 m<sup>2</sup>/LT. for a coating (it may vary

according to the roughness, surface absorption and application methods)

**stability:** 24 months, stock between +5°C and +30°C

**colours:** white and coloured

**packaging:** LT. 1 -LT. 2,5 - LT. 5- LT. 12

**on the surface** 2 hours at 20°C

**overpainting :** 4 - 6 hours at 20°C

**in depth:** 24 hours at 20°C

**DRYING:**

**CHARACTERISTICS AND RESISTANCE:**

Primer 1200 is a waterbased products of easy application characterised by a good covering, resistance and washability. It can be applied on several surfaces as cement, plaster, plaster of Paris, plasterboard, wood and iron and even on surfaces that have already been painted (provided that the existing coat is not peeling)

**PREPARATION OF THE PRODUCTS:**

**APPLICATION:**

**dilution:** To be diluted at 15-20% with water

**system:** by brush-by roller-by spray

**number of coatings:** 1 - 2

**PREPARATION OF THE SURFACE:**

**FOR VELIDOR FINE Old walls.** Remove old non-adhering and peeling paint and wash using water and a suitable soap product. Next, apply a coating of Primer 1200 diluted 50% with water to act as a fixative. After approximately 4 hours at 20°C, apply a second coat of PRIMER 1200 diluted 15 - 20% with water. If, however, the surfaces are clean and not peeling, apply one or two coats of PRIMER 1200 diluted 15 - 20% with water. After 4 hours at 20°C, proceed with the application of VELIDOR FINE.

**New Surfaces.** Use a filler to repair the surface. When dry, sand the surface then apply one or two coats of PRIMER 1200 diluted 15 - 20% with water. After 4 hours at 20°C, proceed with the application of VELIDOR FINE

**FOR ARTECO' 7 METAL:** Apply on new or old walls provided they are in good condition and are not oily, dusty or damp. Otherwise, treat them adequately and apply a suitable fixative. Subsequently, apply one covering coat of PRIMER 1200 diluted 15 - 20% using a woolen roller or brush (or sprayer) with criss-cross strokes for improved coverage. After 6 hours at 20°C, proceed with the application of ARTECO' 7 METAL.

## SC 00239

**For Klondike Corten Smooth surfaces:** Strip away old peeling paint or crumbling paint and wash with adequate soap. Next, apply filler where necessary to obtain a uniform surface. Once the surface dries, sand it and apply a suitable fixative, especially on lime-washed surfaces or on lime-based plasters. Next, apply PRIMER 1200 with a woollen roller or brush or sprayer with criss-cross strokes for improved coverage.

After 6 hours at 20°C, apply KLONDIKE CORTEN

**FOR METEORE 10 CEMENTO :** Make sure that the surface is stable and remove any impurities. Eliminate any old flaky or crumbling paint and wash with an appropriate soap. Then plaster the surface where necessary and apply a fixative after the plaster has dried. Apply PRIMER 1200 with a felt roller, brush or spray. After 6 hours at 20°C, apply METEORE 10 and finish with C100 OVER.

### NOTES:

Temperature of application must be between +5°C and +30°C. Keep away from frost. Wash the tools soon after use with water and soap.

**Technical Sheet n° SC 00239 issued by the Responsible Quality Control:**

**Edition n° 4**

**June 2016**

**Page 2/2**