



VALPAINT S.p.A.
Via dell'Industria, 80 - 60020 POLVERIGI (AN) ITALY
Tel. +39 071 906383 (r.a.) - Fax +39 071 906384
E-mail: info@valpaint.it
C.F./P.IVA/R.I. di AN 01108220425
Capitale Sociale € 500.000,00 i.v.

www.valpaint.it • www.valpaintjungle.it

SC 00186

PRIMER 400

Technical Sheet

NAME:
TYPE:
USE:
COMPOSITION:
SOLVENTS:
CHARACTERISTICS:

PRIMER 400

white water-based paint
water-based primer for interior easily to apply
special resins and charges which allow transpirability
water

specific weight: 1.420 ± 30 gr/LT. at 20°C
yield: 12 - 14 m²/LT. one coating
6-7 m²/LT two coatings (may vary according to the roughness, surface absorption and application method)

stability: 24 months, stock between +5°C and +30°C
colours: white an coloured
packaging: LT. 0,750 - LT. 5
on the surface: 2 hours at 20°C
overpainting: 2 - 4 hours at 20°C
in depth : 24 hours at 20°C

DRYING:

CHARACTERISTICS AND RESISTANCE

Primer 400 is a water-based product endowed with particular characteristics which make it similar to a solvent – based product as for instance its penetration in the surface. PRIMER 400 is easy to apply, is washable and remains strong, and it has an excellent coverage.

It may be applied to many different surfaces, for example cement, plaster, plaster of Paris, plasterboard, wood, iron PVC and even surfaces that have already been painted (provided that the existing coat is not peeling).

PRIMER 400 is excellent as a top coat of paint both indoors and outdoors and no fixative paints are needed

dilution: dilute at 10 - 30% with water.

PREPARATION OF THE PRODUCTS:

APPLICATION:

system: by brush-by roller-by spray

Number of coatings: 1 or more coatings

PREPARATION OF THE SURFACE

FOR VALRENNÀ: Old Surfaces. Remove old non-adhering and peeling paint, then wash using water and suitable soap products. Next, use a filler to repair the surface. When drying is complete, sand the surface. Then apply PRIMER 400 to the filled parts only. After approximately 4 hours at 20°C, apply a coat of PRIMER 400 coloured and diluted 10 - 30% with water. If, however, the surfaces are clean and not peeling, apply a covering coat of PRIMER 400 coloured and diluted 10 - 30% with water. After 4 hours at 20°C, proceed with the application of VALRENNÀ.

New Surfaces. Use a filler to repair the surface. When dry, sand and apply PRIMER 400 to the filled parts only. After approximately 4 hours at 20°C, apply a coat of PRIMER 400 coloured and diluted 10 - 30% with water. After another 4 hours at 20°C, proceed with the application of VALRENNÀ

page 1 of 3

SC 00186

FOR ARTECO' 1: Old Exterior Walls: Remove all poorly-anchored and crumbling coatings, wash with water and a suitable soap. Then, apply a coating of PRIMER 400 as fixative diluted at 50% with water and after about 4 hours at 20°C apply a second coating of PRIMER 400 diluted at 30% with water. After 4 hours at 20°C keep on ARTECO' 1 application.

New Exterior Walls: fill adequately the surface to treat where necessary with STUCCO FAST 150. Once the surface is dry after approximately 8 hours at 20°C sand and apply a coating of PRIMER 400 (water-based). After 4 hours at 20°C keep on with ARTECO' 1 application.

Wood, PVC, Glass, Light Alloys and Painted Iron: degrease and sand perfectly the surface to improve adhesion, then apply a coatings of PRIMER 400 (waterbased). After 4 hours at 20°C keep on with ARTECO' 1 application.

New Iron (not treated): degrease the surface removing perfectly any possible rust coats, apply one (or more) coating of WIKTOR water-based antirust. Once dry, after about 4 hours at 20°C apply a coating of PRIMER (waterbased). After 8 hours at 20°C, keep on with ARTECO' 1 application.

FOR ANTICANDO: Old walls. Remove old non-adhering and peeling paint from the support and wash using water and a suitable soap product. Next, apply a coat of PRIMERT 400 diluted 50% with water to act as a fixative. After approximately 4 hours at 20°C, apply a second brushed coat of PRIMER 400 diluted 20 - 30% with water. If, however, the surfaces are clean and not peeling, apply a coat of PRIMER 400 diluted 20 - 30% with water. After 4 hours at 20°C, proceed with the application of ANTICANDO

New walls. Stucco the surface where necessary using VALSTUC. When dry, after approximately 4 hours at 20°C, sand the surface then apply a coat of PRIMART 400 diluted 15 - 20% with water. After 4 hours at 20°C, proceed with the application of ANTICANDO

Wood, glass, light alloys and painted iron. Degrease and sand the surface well to improve adhesion, then apply a coat of PRIMER 400 diluted 15 - 20% with water. After 4 hours at 20°C, proceed with the application of ANTICANDO.

New iron (not treated). Remove all grease and any layers of rust from the surface and apply one coat (or more) of WIKTOR water-based anti-rust treatment. When dry, after approximately 4 hours at 20°C, apply a coat of PRIMER 400 diluted 15 - 20% with water. After 8 hours at 20°C, proceed with the application of ANTICANDO. After 4 hours at 20°C proceed with the application of ARTECO' 7.

FOR VALSETIN: Old and New Surfaces. Remove old non-adhering and peeling paint and wash using a suitable soap product. When the surface is dry, fill any cracks. Once the filler has dried, sand the surface to make sure it is smooth. Next, apply a coat of PRIMER 400 diluted 50% with water to act as a fixative. After approximately 4 - 6 hours at 20°C, smooth over a second coat of undiluted PRIMER 400.



VALPAINT S.p.A.
Via dell'Industria, 80 - 60020 POLVERIGI (AN) ITALY
Tel. +39 071 906383 (r.a.) - Fax +39 071 906384
E-mail: info@valpaint.it
C.F./P.IVA/R.I. di AN 01108220425
Capitale Sociale € 500.000,00 i.v.

www.valpaint.it • www.valpaintjungle.it

SC 00186

Next, apply undiluted PRIMER 400 to the filled areas only; after 4 - 6 hours at 20°C smooth PRIMER 400 over the entire surface using a Wool Roller, with as many criss-crossed strokes as possible so as to achieve optimal surface coverage. After 4 hours at 20°C, proceed with the application of VALSETIN.

N.B: The PRIMER 400 should be coloured before application, in accordance with the selected VALSETIN colour.

FOR SABULA 2: Old Surfaces. Remove old non-adhering and peeling paint and wash using a suitable soap product. When the surface is dry, fill any cracks. Once the filler has dried, sand the surface to make sure it is smooth. Next, apply a coat of PRIMER 400 diluted 50% with water to act as a fixative. After approximately 4 - 6 hours at 20°C, apply a second coat of PRIMER 400 diluted 20 - 25% with water. PRIMER 400 should be applied with a wool roller, using as many criss-crossed strokes as possible in order to achieve optimal surface coverage. After 6 hours at 20°C, proceed with the application of SABULA 2.

New Surfaces. Smoothen the surface with sandpaper only where necessary. Next, apply PRIMER 400 diluted 20 - 25% with water only over the areas treated with filler; after 4 - 6 hours at 20°C, apply PRIMER 400 over the entire surface using a wool roller, with as many criss-crossed strokes as possible to ensure optimal surface coverage. After another 6 hours at 20°C, proceed with the application of SABULA 2.

FOR POLISTOF: Old Surfaces: remove old non adhering and peeling paint, the wash using water and suitable soap product. Next, use a filler to repair the surface. When dry, sand. Then apply Primer 400 to the filled parts only. Then apply P Primer 400 coloured and diluted 10-30% with water

If however the surfaces are clean and not peeling , apply a coat of PRIMER 400 diluted 10-30% with water. After 4 hours at 20°C proceed with the application of Polistof , New Surfaces: use a filler to repair the surface. When dry, sand and apply PRIMER 400 to the filled part only . After approximately 4 hours at 20°C apply a coat of Primer 400 coloured with the application of POLISTOF

N.B.: for all the Effect except for Jeans Fabric Effect and Shantung Fabric Effect Primer 400 should be coloured in a shade similar to Polistof one using COLORI' coloring paste or VALCLONE Dispensing System

NOTES: Temperature of application and stocking must be between +5°C and +30°C. Keep away from frost. Tools must be cleaned soon with water and soap after use .

Technical Sheet n° SC 00186 issued by the Responsible Quality Control:

Edition n° 11

June 2014



VALPAIN S.p.A.
Via dell'Industria, 80 - 60020 POLVERIGI (AN) ITALY
Tel. +39 071 906383 (r.a.) - Fax +39 071 906384
E-mail: info@valpaint.it
C.F./P.IVA/R.I. di AN 01108220425
Capitale Sociale € 500.000,00 i.v.

www.valpaint.it • www.valpaintjungle.it

page 3 of 3

VALPAIN ESPAÑA S.L.
Carrer de L'Enginy, 11
08840 VILADECANS - ESPAÑA
Tel. +34 93 6382645
Fax +34 93 6382735
E-mail: info@valpaint.es

VALPAIN DESIGN D.O.O.
Džemala Bjedića, 281
71000 SARAJEVO - BiH
Tel. +387 33 626134
Fax +387 33 761115
E-mail: valpaint@bih.net.ba

VALPAIN TUNISIE S.A.
Zone Industrielle Zaghouan
1100 ZAGHOUAN - TUNISIE
Tel. +216 72 681051 / +216 71 751223
Fax +216 72 681071 / +216 71 751344
E-mail: valpaint.tunisie@valpaint.com.tn